

Quick Reference Card DCS Disaster XTS 2500 III Portable

Talkgroup/Channel selection →
ABC Zone selection →
On/Off volume →

PTT →
RSSI →
Backlight →
Battery →



Quick Reference Card

DCS Disaster

XTS 2500 III Portable

Zone A	Zone B	Zone C
DISASTER	NS MA 1	NS MA 1
SHUBIE	NS MA 2	NS MA 2
PATCH 1	NS MA 3	NS MA 3
PATCH 2	NS MA 4	NS MA 4
PATCH 3	NS MA 5	NS MA 5
ALERT	NS MA 6	NS MA 6
EMO ALL1	NS MA 7	NS MA 7
EMO ALL2	NS MA 8	NS MA 8
EMO WEST	COMMON 1	COMMON 1
EMOSOUTH	COMMON 2	COMMON 2
EMO CENT	CONV RP1	CONV RP1
EMO EAST	CONV RP2	CONV RP2
EHS-VOLS	SX ALL 1	SX ALL 1
RCMP-VOL	SX ALL 2	SX ALL 2
GSAR-ALL	SX ALL 3	SX ALL 3
DISASTER	SX PNS	SX PNS